

Deliverable 2D

Perform this first set of operations for all three datasets.

Prepare a separate directory for each project, with subdirectories as needed.

First let's describe the data we have. For each set of fastq files, describe:


1. How many reads are in each file
 1. Lambda
 1. Reads 1.fq – 16874 paired
 2. Reads 2.fq – 16794 paired
 3. Longreads.fq 10458 single
 2. Ppar
 1. SRR6805880.tiny.fastq – 1000
 2. SRR6805881.tiny.fastq – 1248
 3. SRR6805882.tiny.fastq – 1104
 4. SRR6805883.tiny.fastq – 1134
 5. SRR6805884.tiny.fastq – 1173
 6. SRR6805885.tiny.fastq – 1258
 3. Day
 1. 10_S1_L001_R1_001.fastq – 28893152
 2. 10_S1_L001_R2_001.fastq – 28893152
 3. 11_S1_L001_R1_001.fastq – 29291552
 4. 11_S1_L001_R2_001.fastq – 29291552
 5. 12_S1_L001_R1_001.fastq – 29043844
 6. 12_S1_L001_R2_001.fastq – 29043844
 7. 13_S1_L001_R1_001.fastq – 29023016
 8. 13_S1_L001_R2_001.fastq – 29023016
 9. 14_S1_L001_R1_001.fastq – 24730770
 10. 14_S1_L001_R2_001.fastq – 24730770
 11. 15_S1_L001_R1_001.fastq – 28387419
 12. 15_S1_L001_R2_001.fastq – 28387419
 13. 1_S1_L001_R1_001.fastq – 32833451
 14. 1_S1_L001_R2_001.fastq – 32833451
 15. 2_S1_L001_R1_001.fastq – 33738336
 16. 2_S1_L001_R2_001.fastq – 33738336
 17. 3_S1_L001_R1_001.fastq – 35731214
 18. 3_S1_L001_R2_001.fastq – 35731214
 19. 4_S1_L001_R1_001.fastq – 36678316
 20. 4_S1_L001_R2_001.fastq – 36678316
 21. 5_S1_L001_R1_001.fastq – 36972680
 22. 5_S1_L001_R2_001.fastq – 36972680
 23. 6_S1_L001_R1_001.fastq – 31401357

24. 6_S1_L001_R2_001.fastq – 31401357
25. 7_S1_L001_R1_001.fastq – 35536673
26. 7_S1_L001_R2_001.fastq – 35536673
27. 8_S1_L001_R1_001.fastq – 24498096
28. 8_S1_L001_R2_001.fastq – 24498096
29. 9_S1_L001_R1_001.fastq – 29794050
30. 9_S1_L001_R2_001.fastq – 29794050

2. The length of the reads and if they are single or paired-end
 1. Lambda
 1. Paired; 40-354
 2. Ppar
 1. Single; 80
 3. Day
 1. Paired; very varied
3. The overall quality of the reads and anything to be concerned about
 1. Lambda and ppar both were not the best quality (using head command) and for both there were a lot of random characters and not just letters. For the Day data, there were a lot of letters (way more than random characters) which means it was of higher quality than the other two.
4. Whether they appear to have adapter sequences that need to be trimmed
 1. Lambda and Day did not
 2. Ppar – TGCAG adapter sequence

Collect quality control data on the reads, in the form of an .html file produced by fastqc.

1. Lambda
 1. Reads 1.fq – 16874 paired

 **Basic Statistics**

Measure	Value
Filename	reads_1.fq
File type	Conventional base calls
Encoding	Sanger / Illumina 1.9
Total Sequences	10000
Sequences flagged as poor quality	0
Sequence length	40-354
%GC	49

- 1.
2. Reads 2.fq – 16794 paired

✓ **Basic Statistics**

Measure	Value
Filename	reads_2.fq
File type	Conventional base calls
Encoding	Sanger / Illumina 1.9
Total Sequences	10000
Sequences flagged as poor quality	0
Sequence length	40-366
%GC	49

- 1.
3. Longreads.fq 10458 single

✓ **Basic Statistics**

Measure	Value
Filename	longreads.fq
File type	Conventional base calls
Encoding	Sanger / Illumina 1.9
Total Sequences	6000
Sequences flagged as poor quality	0
Sequence length	40-2561
%GC	50

- 1.
2. Ppar
1. SRR6805880.tiny.fastq – 1000

✓ **Basic Statistics**

Measure	Value
Filename	SRR6805880.tiny.fastq.gz
File type	Conventional base calls
Encoding	Sanger / Illumina 1.9
Total Sequences	1000
Sequences flagged as poor quality	0
Sequence length	80
%GC	43

- 1.
2. SRR6805881.tiny.fastq – 1248

✓ **Basic Statistics**

Measure	Value
Filename	SRR6805881.tiny.fastq.gz
File type	Conventional base calls
Encoding	Sanger / Illumina 1.9
Total Sequences	1000
Sequences flagged as poor quality	0
Sequence length	80
%GC	42

- 1.
3. SRR6805882.tiny.fastq – 1104

✓ **Basic Statistics**

Measure	Value
Filename	SRR6805882.tiny.fastq.gz
File type	Conventional base calls
Encoding	Sanger / Illumina 1.9
Total Sequences	1000
Sequences flagged as poor quality	0
Sequence length	80
%GC	42

- 1.
4. SRR6805883.tiny.fastq – 1134

✓ **Basic Statistics**

Measure	Value
Filename	SRR6805883.tiny.fastq.gz
File type	Conventional base calls
Encoding	Sanger / Illumina 1.9
Total Sequences	1000
Sequences flagged as poor quality	0
Sequence length	80
%GC	42

- 1.
5. SRR6805884.tiny.fastq – 1173



Basic Statistics

Measure	Value
Filename	SRR6805884.tiny.fastq.gz
File type	Conventional base calls
Encoding	Sanger / Illumina 1.9
Total Sequences	1000
Sequences flagged as poor quality	0
Sequence length	80
%GC	42

1.

6. SRR6805885.tiny.fastq – 1258



Basic Statistics

Measure	Value
Filename	SRR6805885.tiny.fastq.gz
File type	Conventional base calls
Encoding	Sanger / Illumina 1.9
Total Sequences	1000
Sequences flagged as poor quality	0
Sequence length	80
%GC	42

1.

If the sequences of a project need trimming, perform this step as described in the Marine Genomics tutorial, using cutadapt.

Ppar → wrote a shell script

For filename on *.tiny.fastq.gz

Do

Base=\$(basename \$filename .tiny.fastq.gz)

Echo \${base}

Cutadapt -g TGCAG \${base}.tiny.fastq.gz -o \${base}.tiny_trimmed.fastq.gz

Done

For now, leave the Day data and perform the rest of the operations only on the lambda phage and Ppar (sea cucumber) data.

Index the genome for each species using bowtie.

(/courses/BIOL3411.202430/shared/cutadapt_env) [vyas.aas@c0184 week4]\$ bowtie2-build ppar_tinygenome.fna.gz ppar_tinygenome

[vyas.aas@login-00 lambda]\$ bowtie2-build lambda.fasta lambda

Map the reads to the genome using bowtie. (How is the command used in the Marine Genomics tutorial different from that used in the bowtie tutorial?)

Ppar →

For filename on *.tiny_trimmed.fastq.gz

Do

```
Base=$(basename $filename .tiny_trimmed.fastq.gz)
```

```
Echo ${base}
```

```
Bowtie2 -x ppar_tinygenome -U ${base}.tiny_trimmed.fastq.gz -S ${base}.sam
```

Done

Lambda →

```
[vyas.aas@c0184 lambda]$ bowtie2 -x  
/home/vyas.aas/2B_deliverable/lambda/bowtie2/example/index/lambda_virus -1  
/home/vyas.aas/2B_deliverable/lambda/bowtie2/example/reads/reads_1.fq -2  
/home/vyas.aas/2B_deliverable/lambda/bowtie2/example/reads/reads_2.fq -S eg2.sam
```

10000 reads; of these:

10000 (100.00%) were paired; of these:

834 (8.34%) aligned concordantly 0 times

9166 (91.66%) aligned concordantly exactly 1 time

0 (0.00%) aligned concordantly >1 times

834 pairs aligned concordantly 0 times; of these:

42 (5.04%) aligned discordantly 1 time

792 pairs aligned 0 times concordantly or discordantly; of these:

1584 mates make up the pairs; of these:

1005 (63.45%) aligned 0 times

579 (36.55%) aligned exactly 1 time

0 (0.00%) aligned >1 times

94.97% overall alignment rate

Convert the files containing mapped reads from sam to bam files using samtools.

There are two programs for determining variants (positions where the read sequences differ from the reference genome) that we were introduced to: bcftools and angsd. Use each of these to call variants for the lambda phage and sea cucumber data, and compare the results.

***Ppar* →**

For filename on *.tiny_trimmed.fastq.gz

Do

```
Base=$(basename $filename .tiny_trimmed.fastq.gz)
```

```
Echo ${base}
```

```
Bowtie2 -x ppar_tinygenome -U ${base}.tiny_trimmed.fastq.gz -S ${base}.sam
```

Done

***Lambda* →**

```
[vyas.aas@c0184 lambda]$ module load samtools/1.9
```

```
[vyas.aas@c0184 lambda]$ samtools view -bS eg2.sam > eg2.bam
```

```
[vyas.aas@c0184 lambda]$ samtools sort eg2.bam -o eg2.sorted.bam
```

```
[vyas.aas@c0184 lambda]$ ls
```

```
eg1.sam  eg2.bam  eg2.raw.bcf  eg2.sam  eg2.sorted.bam  eg3.sam  lambda_virus.fa  
lamda_virus.1.bt2  lamda_virus.2.bt2  lamda_virus.3.bt2  lamda_virus.4.bt2  lamda_virus.rev.1.bt2  
lamda_virus.rev.2.bt2
```

angsd

***ppar* →**

For filename on *.sam

Do

```
Base=$(basename $filename .sam)
```

Echo \${base}

Samtools view -bhS \${base}.sam | samtools sort -o \${base}.bam

Done

Then we activate it using source activation from the shared folder.

```
[vyas.aas@c0184 week4]$ /courses/BIOL3411.202430/shared/angsd_env/angsd/angsd -bam  
bam.filelist -GL 1 -out genotype_likelihooods -doMaf 2 -SNP_pval 1e-2 -doMajorMinor 1
```

And then →

```
(/courses/BIOL3411.202430/shared/cutadapt_env) [vyas.aas@c0184 week4] gunzip  
genotype_likelihooods.mafs.gz
```

```
(/courses/BIOL3411.202430/shared/cutadapt_env) [vyas.aas@c0184 week4] cat *.mafs
```

Chromo	position	major	minor	unknownEM	pu=EM	nInd
KN882277.1	41498	G	T	0.332737	3.127339e-03	3
KN885472.1	10712	C	G	0.126253	1.118604e-03	6
KN885472.1	10741	T	A	0.205533	2.729806e-03	6
KN885472.1	10746	C	T	0.113382	1.394211e-03	6
KN894013.1	22082	T	C	0.098327	3.551274e-03	2
KN894013.1	22084	C	T	0.106562	3.241062e-03	2
KN883616.1	31041	C	A	0.422659	2.070393e-03	3
KN883616.1	31042	T	G	0.424129	1.269827e-03	3
KN883758.1	179190	A	T	0.336645	3.103740e-03	3

Lambda →

Converted sam to bam again

```
(/courses/BIOL3411.202430/shared/bcftools_env) [vyas.aas@c0184 lambda]$ bcftools mpileup -f  
/courses/BIOL3411.202430/students/vyas.aas/2B_deliverable/lambda/bowtie2/example/referenc  
e/lambda_virus.fa eg2.sorted.bam | bcftools view -Ov -> eg2.raw.bcf
```

[mpileup] 1 samples in 1 input files

```
(/courses/BIOL3411.202430/shared/bcftools_env)[vyas.aas@c0184 lambda]$ bcftools view eg2.raw.bcf
```

HUGE FILE OUTPUT - did not include all data

```
##fileformat=VCFv4.2  
##FILTER=<ID=PASS,Description="All filters passed">  
##bcftoolsVersion=1.6+htslib-1.6  
##bcftoolsCommand=mpileup -f  
/courses/BIOL3411.202430/students/vyas.aas/2B_deliverable/lambda/bowtie2/example/reference/lambda_virus.fa eg2.sorted.bam  
##reference=file:///courses/BIOL3411.202430/students/vyas.aas/2B_deliverable/lambda/bowtie2/example/reference/lambda_virus.fa  
##contig=<ID=gi|9626243|ref|NC_001416.1|,length=48502>  
##ALT=<ID=*,Description="Represents allele(s) other than observed.">  
##INFO=<ID=INDEL,Number=0,Type=Flag,Description="Indicates that the variant is an INDEL.">  
##INFO=<ID=IDV,Number=1,Type=Integer,Description="Maximum number of reads supporting an indel">  
##INFO=<ID=IMF,Number=1,Type=Float,Description="Maximum fraction of reads supporting an indel">  
##INFO=<ID=DP,Number=1,Type=Integer,Description="Raw read depth">  
##INFO=<ID=VDB,Number=1,Type=Float,Description="Variant Distance Bias for filtering splice-site artefacts in RNA-seq data (bigger is better)",Version="3">  
##INFO=<ID=RPB,Number=1,Type=Float,Description="Mann-Whitney U test of Read Position Bias (bigger is better)">  
##INFO=<ID=MQB,Number=1,Type=Float,Description="Mann-Whitney U test of Mapping Quality Bias (bigger is better)">  
##INFO=<ID=BQB,Number=1,Type=Float,Description="Mann-Whitney U test of Base Quality Bias (bigger is better)">  
##INFO=<ID=MQSB,Number=1,Type=Float,Description="Mann-Whitney U test of Mapping Quality vs Strand Bias (bigger is better)">  
##INFO=<ID=SGB,Number=1,Type=Float,Description="Segregation based metric.">  
##INFO=<ID=MQ0F,Number=1,Type=Float,Description="Fraction of MQ0 reads (smaller is better)">  
##INFO=<ID=I16,Number=16,Type=Float,Description="Auxiliary tag used for calling, see description of bcf_callret1_t in bam2bcf.h">  
##INFO=<ID=QS,Number=R,Type=Float,Description="Auxiliary tag used for calling">  
##FORMAT=<ID=PL,Number=G,Type=Integer,Description="List of Phred-scaled genotype likelihoods">  
##bcftools_viewVersion=1.6+htslib-1.6  
##bcftools_viewCommand=view -Ov -; Date=Thu Mar 14 17:22:29 2024  
##bcftools_viewCommand=view eg2.raw.bcf; Date=Thu Mar 14 17:22:41 2024
```


#CHROM	POS	ID	REF	ALT	QUAL	FILTER	INFO	FORMAT	
gi 9626243 ref NC_001416.1	1	.	G	<*>	0	.			
							DP=1;l16=0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,QS=0,0;MQOF=0	PL	0,0,0
gi 9626243 ref NC_001416.1	2	.	G	<*>	0	.			
							DP=2;l16=0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,QS=0,0;MQOF=0	PL	0,0,0
gi 9626243 ref NC_001416.1	2	.	GGCG	GGCGCGGGGCGG	0	.			
							INDEL;IDV=1;IMF=0.5;DP=2;l16=1,0,1,0,0,0,41,1681,24,576,42,1764,1,1,0,0,QS=0.0888889,0.91111;VDB=0.02;SGB=-0.379885;MQOF=0	PL	36,1,0
gi 9626243 ref NC_001416.1	3	.	G	<*>	0	.			
							DP=2;l16=0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,QS=0,0;MQOF=0	PL	0,0,0
gi 9626243 ref NC_001416.1	4	.	C	<*>	0	.			
							DP=3;l16=0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,QS=0,0;MQOF=0	PL	0,0,0
gi 9626243 ref NC_001416.1	5	.	G	<*>	0	.			
							DP=3;l16=0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,QS=0,0;MQOF=0	PL	0,0,0
gi 9626243 ref NC_001416.1	6	.	G	<*>	0	.			
							DP=3;l16=0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,QS=0,0;MQOF=0	PL	0,0,0
gi 9626243 ref NC_001416.1	7	.	C	<*>	0	.			
							DP=3;l16=0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,QS=0,0;MQOF=0	PL	0,0,0
gi 9626243 ref NC_001416.1	8	.	G	<*>	0	.			
							DP=3;l16=0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,QS=0,0;MQOF=0	PL	0,0,0
gi 9626243 ref NC_001416.1	9	.	A	<*>	0	.			
							DP=3;l16=0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,QS=0,0;MQOF=0	PL	0,0,0